

BYRNE

INSTALLATION INSTRUCTIONS FOR START EDGE MOUNT.

- Install the jacks for the desired data connections in the free ports, using the attached instructions for the Voice and Data Adapters Kit (BE01421). Wire the jacks according to requirements.
- Slide the power cables and the voice and data transmission cables through the START rear cover.
- Slide START onto the work platform. Make sure the bracket under the START base is completely inside the surface.
- Tighten knobs until START is locked.

