

# Levity<sup>®</sup>

## Power + Task Light

Pull-up Task Light that adjusts for directed lighting.

Flexible tilt option enables omnidirectional movement.

Maximum height of 21"

1 Power Outlet, 1 Dual USB Charger


LED lights offer 35,000 hours or 17 years of continuous use.

### Product Includes

1 Levity Task Light





4 Mounting Brackets

4 Thumb Screws







### Front Mount Installation Instructions

Only install in table with a maximum thickness of 2"

<p><b>1</b> Cut a hole 8-5/8" x 2" <i>Jigsaw is suggested</i></p> 	<p><b>2</b> Place Levity unit into opening.</p> 	<p><b>3</b> Attach mounting brackets and thumb screws. <i>Front/back mounting brackets use 2 thumb screws each.</i></p> 	<p><b>4</b> Slide mounting brackets against the bottom of the table. Tighten thumb screws to hold in place.</p> 
---	--	--	---

### Side Mount Installation Instructions

Only install in table with a maximum thickness of 2"


<p><b>1</b> Cut a hole 8-5/8" x 2" <i>Jigsaw is suggested</i></p> 	<p><b>2</b> Place Levity unit into opening.</p> 	<p><b>3</b> Attach mounting brackets and thumb screws. <i>Side mounting brackets use 1 thumb screw each.</i></p> 	<p><b>4</b> Slide mounting brackets against the bottom of the table. Tighten thumb screws to hold in place.</p> 
---	---	---	---



## How to Activate Light

Manually raise unit 4 or more inches.

While raised, turn the light on or off by touching the middle of the lamp area.



## Safety Information

Risk of electrical shock

Do not disassemble

Use only in dry locations

Tripping hazard. Do not place cord in pathway or high traffic areas.

Check cord and all other parts for damage. If any part is pinched or damaged the product should not be used.

Strangulation hazard. Cords may pose risk of strangulation for children.

Keep power unit and cord out of reach of small children.

Always push the plug all the way into the power outlet to avoid electrical shock.

Do not unplug by pulling on cord. Grasp plug to remove from outlet.

## Warranty

We, the manufacturer, warrant Byrne products to be free from defects in material and workmanship under normal use and service for a period of one (1) year from the date of manufacture. We will refund the price of the defective product, repair or replace, at our option, products which prove to be defective within the warranty period. If product is repaired or replaced it will be shipped F.O.B. manufacturer's facility. If we determine to refund the price of a product, we may require that the product be returned to us before the refund is given. This warranty shall be voided by any repair alteration, or modification by persons other than the employees of manufacturer, or those who are expressly authorized by manufacturer to make such repairs, and by any abuse, misuse or neglect of the products by use not in accordance with its published instructions. The remedies for any failure of the products to meet its warranty specified herein shall be those remedies stated herein and no other; these remedies being exclusive remedies as a condition of sale irrespective of the theory upon which any claim might be based, including negligence, breach of contract or strict liability. In addition, except as provided in this paragraph or to the extent restricted or prohibited by applicable law, the manufacturer makes no warranty expressed or implied, including any warranty of merchantability or fitness for any particular purpose, and you specifically agree that the manufacturer shall not be liable for any special, incidental, indirect, punitive or consequential damages for breach of any warranty of any type on any Byrne product. In addition to and without limiting the generality of the foregoing disclaimers, the limited warranty does not, under any circumstances, cover the replacement or cost of any electronic device (including but not limited to any mobile phone devices) or personal property outside of the Byrne product.

## Storage

For indoor use only; always store indoors and in a dry location.



## Cleaning

Wipe with damp cloth, never spray directly with water or cleaner.

## Warnings

Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device is in compliance with Part 18 of the FCC Rules and Canadian ICES-001.

This equipment has been tested found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

# BYRNE

Made in China

Patented by Byrne Electrical Specialists, Inc.  
320 Byrne Industrial Dr, Rockford, Michigan, USA

Contact (800) 999-3567 for product FAQs, recycling, replacement or warranty information.

[Byrne.com](http://Byrne.com)

[ByrneElectrical](https://www.facebook.com/ByrneElectrical)

[ByrneElectrical](https://www.instagram.com/ByrneElectrical)



share with us  
**#byrnepower**

